# ECE132: Basic Electrical and Electronics Engineering Lab

#### **Experiment 6:**


To understand use of diodes for half wave and full wave rectifiers

#### Introduction

- A rectifier is an electrical device that converts alternating current (AC), which periodically reverses direction, to direct current (DC), which is in only one direction, a process known as rectification.
- We can classify rectifiers into two types:
  - Half Wave Rectifier
  - Full Wave Rectifier

### Half Wave Rectifier

- In half wave rectification, either the positive or negative half of the AC wave is passed, while the other half is blocked.
- Because only one half of the input waveform reaches the output, it is very inefficient if used for power transfer.




## Half Wave Rectifier

• The output DC voltage of a half wave rectifier can be calculated with the following two ideal equations

$$V_{rms} = \frac{V_{peak}}{2}$$
$$V_{dc} = \frac{V_{peak}}{\pi}$$

## Half Wave Rectifier

#### Halfwave Rectifier Experiment



#### Instructions

- 1. Observe the circuit diagram of the fullwave rectifier
- 2. Click on the **Power** Button.
- 3. Select the Amplitide(A) of the input sine wave signal(V<sub>i</sub>).
- 4. Select the frequency of the signal(f) for the input signal(V<sub>i</sub>).
- 5. Select the "Channel 1" to observe the input signal on graph
- 6. Select the "Channel 2" to observe the rectified output signal on graph
- 7. Select the "Dual" to observe the input signal and rectified output signal on graph
- 8. Change the values of A, f to observe the variation in the input and output signals.
- 9. Hover on the graph to observe the value of the  $V_i$  and  $V_o$  at that instatnt of time T.
- 10. Save the graph if you are done with your experiment.

#### 11. Note:

- o Ideal diode is considered
- Make sure always Input Signal Amplitude>0 v
- Make sure always Input Signal Frequency>0 Hz
- $\circ$  Load resistance  $R=1k\Omega$
- To change the values just scroll by hovering on it.


### Full Wave Rectifier


- In Full wave rectification current flow through the load in same direction for both half cycle of input ac.
- This can be achieved with two diodes working alternatively.
- For one half cycle one diode supplies current to load and for next half cycle another diode works

#### **Full Wave Rectifier**

- For single-phase AC, if the transformer is **center-tapped**, then two diodes back-to-back (i.e. anodes-to-anode or cathode-to-cathode) can form a full-wave rectifier.
- In a circuit with a **non center tapped** transformer, four diodes are required instead of the one needed for halfwave rectification, it is also known as bridge rectifier.

## Full Wave Rectifier – Center Tapped T/F






# Full Wave Rectifier – Center Tapped T/F

• The average and root-mean-square output voltages of an ideal single phase full wave rectifier can be calculated as:

$$V_{dc} = V_{av} = \frac{2V_p}{\pi}$$
$$V_{rms} = \frac{V_p}{\sqrt{2}}$$


# Full Wave Rectifier – Bridge Rectifier

• A bridge rectifier makes use of four diodes in a bridge arrangement to achieve full-wave rectification.




# Full Wave Rectifier – Bridge Rectifier

• A bridge rectifier makes use of four diodes in a bridge arrangement to achieve full-wave rectification.



## **Full Wave Rectifier**



#### Instructions

- 1. Observe the circuit diagram of the fullwave rectifier
- 2. Click on the Power Button.
- 3. Select the Amplitide(A) of the input sine wave signal(V<sub>i</sub>).
- 4. Select the frequency of the signal(f) for the input signal(V<sub>i</sub>).
- 5. Select the "Channel 1" to observe the input signal on graph
- 6. Select the "Channel 2" to observe the rectified output signal on graph
- 7. Select the "Dual" to observe the input signal and rectified output signal on graph
- 8. Change the values of A, f to observe the variation in the input and output signals.
- 9. Hover on the graph to observe the value of the  $V_i$  and  $V_o$  at that instatnt of time T.
- 10. Save the graph if you are done with your experiment.
- 11. Note:
  - V<sub>2</sub> is 180° in phase to V<sub>1</sub>
  - o Ideal diode is considered
  - o Make sure always Input Signal Amplitude>0 v
  - Make sure always Input Signal Frequency>0 Hz
  - $\circ$  Load resistance  $R=1k\Omega$
  - To change the values just scroll by hovering on it.

## THANKS TO ALL